




AP-1110



ALTAVOZ DE TECHO 2 VÍAS COAXIAL (6")

ALTIFALANTE DE TECTO 2 VIAS COAXIAL (6")

2 WAYS COAXIAL (6") CEILING LOUDSPEAKER



CARACTERÍSTICAS TÉCNICAS / CARACTERISTIQUES TECHNIQUES / TECHNICAL CHARACTERISTICS

| | | | |
|---|---|---|--|
| Potencia nominal Potência Nominal Rated Power | 10 - 5 - 2 - 1 - 0,5W rms L100V. | | |
| Diá. altavoz graves (woofer) Dia. altifalante de graves (woofer) Dia. woofer | 6". | Dispersión Angulo Dispersion | 110 °. |
| Diá. altavoz agudos (tweeter) Dia. altifalante de agudos (tweeter) Dia. tweeter | 1". | Material / color plafón Material / Cor Material / colour loudspeaker | ABS autoextinguible A-0 / Blanco RAL 9010. ABS auto extingüivel A-0 / Branco RAL 9010. ABS self-extinguishable A-0 / RAL white 9010. |
| Banda pasante Frequências Frequency range | 60 - 18.000 Hz. | Material / color rejilla Material / cor da grelha Material / colour grill | Aluminio lacado / Blanco RAL 9010. Aluminio lacado laqué / Branco RAL 9010. Lacquered aluminium / RAL white 9010. |
| Sensibilidad Sensibilidade Sensitivity | 90 dB 1W / 1 m / 1 kHz. | Peso Peso Weight | 1,210 Kgs. |



EQUIPOS Y SISTEMAS MEGAFONÍA / INTERCOM • PUBLIC ADDRESS SYSTEMS

UNIÃO DESARROLLOS ELECTRÓNICOS

Tel.: (+351) 229 477 080

• geral@misterpuzzle.pt • MAIA - PORTUGAL



www.udeaudio.com

rev.0 610.285CFA 1 / 2

1

\varnothing max: 205 mm.
 \varnothing min: 195 mm.

Espesor / Espessura / thickness max.: 30 mm. max. falso techo / placa de gesso / Ceiling.

2

- Separar la rejilla de aluminio, empujando los soportes **A**. Guarde cuidadosamente la rejilla.
- Remover a grelha puxando os suportes "A". Guarde cuidadosamente a grelha.
- Remove the aluminium grid pushing the supports "A". Put away carefully the grid.

3

- Conecte los cables en los bornes (**R**) y seleccione la potencia en el transformador (**T**). Gire los soportes (**A**) hacia el interior del plafón.
- Ligue os cabos aos terminais "R" e seleccione a potência desejada do transformador "T". Rode os suportes "A" para o interior da coluna.
- Connect the leads into the terminals "R" and select the power in the transformer "T". Rotate the supports "A" towards the interior of the ceiling loudspeaker.

4

- Introduzca el altavoz en el orificio efectuado en el falso techo.
- Introduza o altifalante no recorte feito no tecto.
- Introduce the loudspeaker in the hole made in the ceiling.

5

- Atornillar los 4 tornillos (**B**) hasta que el altavoz quede firmemente sujeto.
- Aparafusar os 4 parafusos "B" até que o altifalante esteja firmemente fixado.
- Screw on the 4 bolts "B" until the loudspeaker gets firmly tighten.

6

- Colocar la rejilla de aluminio en su alojamiento.
- Colocar a grelha.
- Place the aluminium grid in its housing.